

AnaCONT

COMPACT, CONDUCTIVITY TRANSMITTERS

Ц

New!



FEATURES


- Compact and mini compact versions
- Separated versions up to 10m
- Measuring range: 0.1 μS/cm 20 mS/cm
- Replaceable or built-in probes
- Wide range of probes
- Cell constants: K=0.01; K=0.1; K=1
- Temperature compensation
- Graphical plug-in display
- Optional external display
- 4..20 mA / HART / Relay output


OPERATION

Two probes are immersed into the measured liquid. The distance between the probes and their surface define the cell constant (K) of the instrument.

Connecting AC voltage to the electrodes the electronics measures the conductivity of the liquid between the probes. This measured value is converted to 4...20 mA output signal.

The cell constant defines the measuring range and thus the application area.





TECHNICAL DATA

ТҮРЕ		AnaCONT L□ K (compact)	AnaCONT LC□ (mini compact)				
Measurement data	Range	0.1 μ S/cm $-$ 20 mS/cm	1 μ S/cm $-$ 2000 μ S/cm				
	Accuracy	0.1 % ±1 digit ±0,01 %/°C	3 % ±1 digit				
Temperature measurement		Range: -50 °C +130 °C; Accuracy: ±0.5 °C; Resolution: 0.1 °C					
Power supply		12-36 V DC galvanic isolation, protected against surge transients					
Probe input		2-wire conductive, galvanic isolation					
Probe		Replaceable	Built-in				
		Cell constant K=0.01; K=0.1; K=1					
Output	Analogue	4 20 mA					
	Relay	SPDT 30 V DC, 1 A DC	-				
	Display	SAP-300 dot matrix	Optional: Unicont PLK-501, external				
	Digital	HART					
Process temperature		-10 °C +90 °C					
Process pressure		0-1.6 MP (0-16 bar)					
Ambient temperature		-10 °C +70 °C					
Sealings		EPDM, Viton	Viton				
Ingress protection		IP68 / IP67					
Housing material		Plastic, Aluminium	1.4571 Stainless Steel				
Material of probe socket		St. st. + PP, PVDF, epoxi	St.st. + PP				
Electrical connection		2 x M20 x1.5 cable gland	DIN43650 connector				
Electrical protection		Closs III.					
Ex marking		II 1 G EExia IIB T6 IP67	-				



ORDER CODE

AnaCONT IN SYSTEM WITH A PC

The instrument with HART output can be connected to a PC using a SAT-304 HART-USB modem. Max. 15 normal (non Ex) instruments can be connected to a HART line. Measured values can be

visualised and/or the instruments can be programmed via digital HART communication. Applicable software: **EView** configuration software or **NIVISION** process visualization software.



AnaCONT IN SYSTEM WITH MULTICONT

MULTICONT can handle a max. of 15 HART capable transmitters (conductivity, pH, ORP, temperature, level, pressure). The digital (HART) information is processed, displayed and if needed it can be transmitted via RS485 communication line to a PC. Remote programming of the transmitters is also possible. Visualisation on PC can be accomplished with **NIVISION** process visualization software.

AnaCON1	r L	K -	*						
Туре	Code	Hous	ing mat.	Code	Proc. c	onn. / Mat.	Code	Output / Ex	Code
Compact	Е	Plastic		1	BSP 11/2 " / PP		1	420 mA	2
Compact	G	Aluminium		2	BSP 11/2 " / PVDF		2	420 mA+HART	4
+ display	U					NPT 11/2 " / PP		420 mA / Ex	6
AnaCONT mini compact conductivity transmitters				rs	NPT 11/2 " / PVDF		5	420 mA+HART / Ex	8
AnaCONT LCK - 2								420 mA / Relay	R
								420 mA+HART / Relay	Н
Measuring	range	Code	Process	conn.	Code	Output	Code		
1-20 μS/cm (K=0.01)		1	BSP 3/4"		1	420 mA	2	Measuring range	Code
10-200 μS/cm (K=0.1) 100-2000 μS/cm (K=1)		2	BSP 1"		2	420 mA	4	0.1-20 µS/cm (K=0.01)	1
		3	(only with	(only with $K=1$ probe)		+HART	4	$1-200 \mu\text{S/cm} (K=0.1)$	2
* the order code of an Ex version should end in 'Ex' 1-20 mS/cm (K=1									3